

WES-237A Final Project - Contactless Health Monitoring

David Rodriguez & Yaqoob Hanona

Group 2

11 March 2023

Part 1: Importing Libraries

```
In [1]: import time
import serial
import socket

import subprocess
import multiprocessing
import pynq.lib.rgblcd as rgblcd
from pynq.overlays.base import BaseOverlay
from pynq.lib import MicroblazeLibrary

from pynq.lib.arduino import Arduino_Analog
from pynq.lib.arduino import ARDUINO_GROVE_A1
from pynq.lib.arduino import arduino_io

base = BaseOverlay("base.bit")
analog1 = Arduino_Analog(base.ARDUIO, ARDUINO_GROVE_A1)

btns = base.buttons[0:3] # Define List containing all built-in Buttons
```

Part 2: Microblaze Functions

```
In [2]: %%microblaze base.PMODB
#include "gpio.h"
#include "pyprintf.h"

// Function to turn on/off a selected pin of PMODB
int write_gpio(unsigned int pin, unsigned int val){
    if (val > 1){
        pyprintf("pin value must be 0 or 1");
    }
    gpio_pin_out = gpio_open(pin);
    gpio_set_direction(pin_out, GPIO_OUT);
    gpio_write(pin_out, val);
}

// Reset GPIOs function - Resets all PMODB GPIOs (0-7) to Logic LOW
void resetGPIOs() {
    for (int pin=0; pin < 7; pin++){ // Iterate for all PMODB GPIO Pins
        write_gpio(pin, 0x00); // calling user defined function
    }
}

void setGreen_HIGH(){
    write_gpio(2, 0x01);
}

void setGreen_LOW(){
    write_gpio(2, 0x00);
}

void setRed_HIGH(){
    write_gpio(3, 0x01);
}

void setRed_LOW(){
    write_gpio(3, 0x00);
}
```

Part 3: Reset GPIOs

```
In [3]: resetGPIOs() # Reset all GPIOs
```

```
In [4]: setGreen_LOW() # Turn Green LED Off
        setRed_LOW() # Turn Red LED Off
```

Part 4: Defining Multiprocessing Processes

```
In [5]: # WES237A Final Project - Multiprocessing Processes

# Define Multiprocassing Manager List
manager = multiprocessing.Manager()
seq_complete_list = manager.list()

setRed_HIGH() # Turn Red LED On = "Not Connected"

serverName = 'ec2-35-90-59-237.us-west-2.compute.amazonaws.com' # AWS Server Public DNS Domain
testUDP_Port = 1113 # TEST UDP Port

clientPort = 11114 # TCP Client Port
port = 11115 # AWS Server TCP Listening Port

def Presence_Detect(): # Gets Presence Detection status from Radar Sensor GPI Pin voltage,
    # then reports status to AWS Server via UDP Connection
    serverName = 'ec2-35-90-59-237.us-west-2.compute.amazonaws.com' # AWS Server Public DNS
    UDPclientPort = 1118
    clientSocket = socket.socket(family=socket.AF_INET, type=socket.SOCK_DGRAM)
    while True:
        analog1.read()
        bits = analog1.read('raw')[1]
        if bits >= 1000:
            message = '1'
        else:
            message = '0'
        time.sleep(0.05)
        print('sending message: {}'.format(message))
        # Connect to AWS Server UDP Port and Send Data
        clientSocket.sendto(message.encode(),(serverName, UDPclientPort))
        time.sleep(9)
        if len(seq_complete_list) > 0:
            break
    clientSocket.close()

def TCP_Online_Status(): # Report Online Status to AWS Server via TCP Connection
    # Create a TCP/IP socket
    c_sock = socket.socket(socket.AF_INET, socket.SOCK_STREAM)
    print('Connecting PYNQ Client. . .')

    # Connect Client
    c_sock.connect((serverName, clientPort))
    print('Connected to AWS Server!')

    setRed_LOW() # Turn Red LED Off
    setGreen_HIGH() # Turn Green LED On

    upMessage = 'up'
    downMessage = 'down'

    while True:
        setGreen_HIGH()
        time.sleep(8)
        c_sock.send(upMessage.encode())

        if len(seq_complete_list) > 0:
            setGreen_LOW()
            setRed_HIGH()
            # Send AWS TCP Server OffLine Message
            c_sock.send(downMessage.encode())
            break

    # Disconnect from Client
    c_sock.close()
    print('Client Connection Socket Closed!')
```

```

def radar():
    presence_detect = 0
    while True:
        serMsg = serial.Serial('/dev/ttyUSB0', 115200, timeout=2)
        #serMsg.flushInput()

        # Read Radar Data from serial port
        ch = serMsg.read(15).hex() # 15 bytes = max frame size for radar module

        FRAME_HEADER = '5359'
        END_OF_FRAME = '5443'

        pt1 = ch.split(FRAME_HEADER)[1]
        pt2 = pt1.split(END_OF_FRAME)[0]

        control_word = pt2[0:2]
        command_word = pt2[2:4]
        data_len = int(pt2[4:8])
        data = pt2[8:(9+data_len)]

        value_list = []

        # Segment Data based on individual Bytes
        if data_len == 1:
            value = int(data, base=16)
            value_list.append(value)
        else:
            for i in range(0, data_len):
                value_segment = str(data[i]) + str(data[i+1])
                value = int(value_segment, base=16)
                value_list.append(value)

        # Heart Rate Value
        if control_word == '85':
            measurement_type = 'HR' # Heart Rate
            if command_word == '02':
                print('Heart Rate Values: ', value_list)
                # Connect to AWS Server UDP Port and Send Data
                clientSocket = socket.socket(family=socket.AF_INET, type=socket.SOCK_DGRAM)
                clientSocket.sendto(str(value_list[0]).encode(),(serverName, 1115))
                clientSocket.close()
            elif command_word == '05':
                print('Heart Rate Waveform: ', value_list)

        # Respiratory Intensity Value
        if control_word == '81':
            measurement_type = 'RM' # Respiratory Monitoring
            if command_word == '02':
                print('Breathing Waveform: ', value_list)
                # Connect to AWS Server UDP Port and Send Data
                clientSocket = socket.socket(family=socket.AF_INET, type=socket.SOCK_DGRAM)
                clientSocket.sendto(str(value_list[0]).encode(),(serverName, 1120))
                clientSocket.close()

            elif command_word == '01':
                print('Breathing Values: ', value_list)

        # Human Presence Status, Distance, and Movement Info
        if control_word == '80':
            measurement_type = 'HP' # Human Presence Info
            movement = ''

            # Human Presence Status
            # NOTE: Although this is redundant to include since Presence_Detect() function fulfills the same purpose,
            # this UDP transmission is only enacted if the Human Presence parameter is detected in the Raw Radar data stream
            if command_word == '01':
                # Presence Status has changed
                if value == 1:
                    print('Presence Detected!')
                    message = '1'
                else:
                    message = '0'
                    print('Presence Not Detected!')
                clientSocket = socket.socket(family=socket.AF_INET, type=socket.SOCK_DGRAM)
                clientSocket.sendto(message.encode(),(serverName, 1118))
                clientSocket.close()

            # Human Movement Status
            if command_word == '02':

```

```

print('Human Movement Info: ', value_list)
if (int(value_list[0]) == 2):
    movement = 'Active'
    movement_status = '02'
elif (int(value_list[0]) == 1):
    movement = 'Stationary'
    movement_status = '01'
else:
    movement = 'None'
    movement_status = '00'
if (len(value_list) == 0):
    movement = 'None'
    movement_status = '00'
print('Movement Status: ', movement)
# Connect to AWS Server UDP Port and Send Data
clientSocket = socket.socket(family=socket.AF_INET, type=socket.SOCK_DGRAM)
clientSocket.sendto(movement_status.encode(),(serverName, 1119))
clientSocket.close()

# Radar Distance Value
if command_word == '04':
    print('Human Distance Info (cm): ', int(pt2[10:12],base=16))
    # Connect to AWS Server UDP Port and Send Data
    clientSocket = socket.socket(family=socket.AF_INET, type=socket.SOCK_DGRAM)
    clientSocket.sendto(str(int(pt2[10:12],base=16)).encode(),(serverName, 1116))
    clientSocket.close()

# Send Raw Data from Radar Module
raw_data = FRAME_HEADER + pt2 + END_OF_FRAME
# Connect to AWS Server UDP Port and Send Raw Data
clientSocket = socket.socket(family=socket.AF_INET, type=socket.SOCK_DGRAM)
clientSocket.sendto(str(raw_data).encode(),(serverName, 1121))
clientSocket.close()

serMsg.close()
time.sleep(0.005)

if len(seq_complete_list) > 0:
    break

```

Part 5: Health Monitoring Program

In [6]: # Define Main Program

```

def main():
    setRed_HIGH() # Turn Red LED On

    print('Press Button to initialize Health Monitoring System')
    while True:
        if btns.read() != 0:
            time.sleep(0.5)
            # Initialize Processes
            print('Initializing Processes')
            break

    # Create 3 Processes
    p0 = multiprocessing.Process(target=radar)
    p1 = multiprocessing.Process(target=TCP_Online_Status)
    p2 = multiprocessing.Process(target=Presence_Detect)

    # Start all Processes
    p0.start()
    p1.start()
    p2.start()

    while True:
        if btns.read() != 0:
            time.sleep(0.5)
            seq_complete_list.append(1)
            setRed_LOW() # Red LED off
            setGreen_LOW() # Green LED off
            break

    time.sleep(2) # Allow sufficient time for socket connections to close

    # Join & Close all Processes
    p0.join()
    p0.close()

```

```

p1.join()
p1.close()
p2.join()
p2.close()

setRed_LOW() # Red LED off
setGreen_LOW() # Green LED off

print('Sequence Stopped!')

if __name__ == '__main__':
    main()

```

```

Press Button to initialize Health Monitoring System
Initializing Processes
Connecting PYNQ Client. . .
sending message: 0
Connected to AWS Server!
Heart Rate Values: [81]
Human Distance Info (cm): 35
Human Movement Info: [1]
Movement Status: Stationary
Human Distance Info (cm): 35
Human Movement Info: [2]
Movement Status: Active
Breathing Waveform: [9]
Heart Rate Values: [83]
Human Distance Info (cm): 35
sending message: 0
Heart Rate Values: [83]
Breathing Waveform: [9]
Human Distance Info (cm):
35Heart Rate Values: [83]
Human Distance Info (cm): 35
Heart Rate Values: [83]
Breathing Waveform:
[9]Human Distance Info (cm):
35sending message: 0
Heart Rate Values:
[83]Human Distance Info (cm): 35
Client Connection Socket Closed!
Sequence Stopped!

```

In []: